



Number	Name
1	Screw
2	Drill Chuck
3	Torque sleeve
4-1	Spindle
4-2	Bearing 689
4-3	Inner thread
4-4	Torque Spring
4-5	Washer
4-6	Pin
4-7	Steel Ball
4-8	Gear Box
4-9	Bearing
4-10	Flat Washer
4-11	Circlip For Shaft
4-12	Flat Washer
4-13	Third layer inner gear ring
4-14	Flat Washer
4-15	Pin
4-16	Third layer planet holder
4-17	Third layer planet gear
4-18	Variable speed dial ring
4-19	Pin
4-20	Variable speed gear ring
4-21	Second layer planet holder
4-22	Second layer planet gear
4-23	First layer planet holder
4-24	First layer planet gear
4-25	First layer inner gear ring
4-26	Washer
4-27	Gear box cover
5	Bearing sleeve
6	Wool washer
7	Bearing 699
8	Armature
9	Bearing 607
10	Stator
11	Tapping screw
12	Right housing
13	Torque shrapnel
14	High/Low speed change knob
15	Spring
16	Led-chimney
17	Reversing pole
18	Carbon brush box
19	Carbon brush
20	Left housing
21	Switch
22	Strain relief

Number	Name
23	Tapping screw
24	Cord guard
25	Cord